IMPORTANT SAFETY INSTRUCTIONS:

(a) READ AND FOLLOW ALL SAFETY INSTRUCTIONS


- b) Do not cover this product as the covering may cause the flexible light to overheat and melt or ignite.
- All units must be unplugged before adding additional segment.
- Use only extension segments model: LED-IF2CH-E.
- Ensure all connections and the end cap on the last segment are tightly secured to preclude the entry of water.
- Do not operate with the flexible light tightly coiled. f)
- Do not puncture, cut, shorten, or splice the flexible lighting.
- Do not route the cord or flexible lighting cable through walls, doors, windows or any like part of the building structure.
- Do not use if there is any damage to the light or cord insulation. Inspect periodically.
- Do not submerge flexible light in liquids, or use the product in the vicinity of standing water or other liquids.
- Secure this flexible light cable using only the hangers or clips provided. Do not secure this product or its cord with staples, nails, or like means that may damage the insulation.
- Do not subject flexible lighting to continuous flexing.
- Do Not Exceed The Maximum Length in Feet Permitted By The Marking.
- This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug, If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

WARNING: When using outdoor use portable lighting products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

Read All Instructions

- Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuits or outlet to be used for the outdoor use flexible lighting product. Receptacles are available having built-in GFCI protection for this measure of safety.
- Use only outdoor extension cords, such as type SW, SOW, STW, STOW, SJW, SJOW, SJTW, or SJTOW. This designation is marked on the wire of the extension cord.


USAGE OF FLEXILIGHT ACCESSORIES



1) With mounting clip (knock the nail into the board surface) (1)Use a nail to fix the

mounting clip;

(2)Press the flexilight into the mounting clip.




2) With suction cups

On the surface of glass or ceramic tile:


(1)Press the suction cup on a glass surface or ceramic tile with glass pattern;

(2) Fix the flexilight on the cupules with mounting clip.



3) With Channel On glass surface: (1)Glue the channel on the

glass surface; (2) Press the flexilight in the channel.



On the surface of wooden material


(1) Fix the channel with nails.

(2)Press the flexilight in the


Extend Flexilights

Maximum length to connect together: 240 feet.

- a. Disconnect power source. Each flexilight is assembled with a power cord on one end, and a cap on the other End.
- b.Flexilight A: Unscrew spiral nut and remove cap from end of flexilight (female connector). Be sure that the rubber-ring stays in place. (The rubber-ring is what makes a water tight seal between sections of flexilights).
- c.Flexilight B: Unscrew spiral nut and remove power cord from the beginning of flexilight (male connector).




male connector flexilight B




e. To add an additional section of flexilight to the end of flexilight B, repeat above procedure.


f. Before connect to power source, make sure all

d.Insert male connector of flexilight B into female connector at end of flexilight A. Then tighten spiral nut of flexilight A over screw threads on connector of flexilight B.






connections and end cap on the last segment are tightly secured to preclude the entry of water.



Fuse Replacement Instructions

- 1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- 2. Slide open fuse access cover on top of attachment plug towards blades.
- 3. Remove fuse carefully by pushing on tabs located next to the blades.
- 4. Set a new fuse into the holder. Use only 125 Volt, 8A fuse.
- 5. Slide closed the fuse access cover on top of attachment plug.



SAVE THESE INSTRUCTIONS

AC 120V, 60Hz, MAX 2A